

# Positek

RIPS® SERIES P502			Part Number Coding						Basic price is for following specifications																													
Small Angle Industrial Rotary Sensor			Travel	Electrical Interface	Sealed Adjuster	Conn / Cable	Option 1	Option 2																														
<table border="1"> <tr> <th colspan="3">Travel</th> </tr> <tr> <td>degrees rotation</td> <td>5° to 20°</td> <td>Value</td> </tr> </table>			Travel			degrees rotation	5° to 20°	Value								<table border="1"> <tr> <th colspan="2">Code</th> </tr> <tr> <td>Electrical</td> <td>A 5V input</td> </tr> <tr> <td>Calibration Adjusters</td> <td>Blank Trim Pots accessible Or / Y Sealed Trim Pots</td> </tr> <tr> <td>Connector/Cable</td> <td>J Integral Hirschmann IP65 connector Or / L50 50 cm screened cable</td> </tr> <tr> <td>Housing</td> <td>Blank Flanged</td> </tr> <tr> <td colspan="2"><b>Travel (customer specified)</b> any angle between 5° and 20°</td> </tr> </table>	Code		Electrical	A 5V input	Calibration Adjusters	Blank Trim Pots accessible Or / Y Sealed Trim Pots	Connector/Cable	J Integral Hirschmann IP65 connector Or / L50 50 cm screened cable	Housing	Blank Flanged	<b>Travel (customer specified)</b> any angle between 5° and 20°											
Travel																																						
degrees rotation	5° to 20°	Value																																				
Code																																						
Electrical	A 5V input																																					
Calibration Adjusters	Blank Trim Pots accessible Or / Y Sealed Trim Pots																																					
Connector/Cable	J Integral Hirschmann IP65 connector Or / L50 50 cm screened cable																																					
Housing	Blank Flanged																																					
<b>Travel (customer specified)</b> any angle between 5° and 20°																																						
<table border="1"> <tr> <th colspan="3">Electrical Interface Options</th> </tr> <tr> <th>Input</th> <th>Output</th> <th></th> </tr> <tr> <td>+ 5V dc nom.± 0.5V</td> <td>0.5 to 4.5V dc ratiometric</td> <td>A</td> </tr> <tr> <td>24V dc nom. +9-28V</td> <td>0.5-4.5V dc</td> <td>G</td> </tr> <tr> <td>±15V dc nom. ±9-28V</td> <td>±5V dc</td> <td>B</td> </tr> <tr> <td>24V dc nom. +13-28V</td> <td>0.5 to 9.5V dc</td> <td>C</td> </tr> <tr> <td>± 15V dc nom. ±13-28V</td> <td>±10 V dc</td> <td>D</td> </tr> <tr> <td>24V dc nom. +18-28V</td> <td>4 to 20mA (2 wire)</td> <td>E</td> </tr> <tr> <td>24V dc nom. +13-28V</td> <td>4 to 20mA (3 wire sink)</td> <td>F</td> </tr> <tr> <td>24V dc nom. +13-28V</td> <td>4 to 20mA (3 wire source)</td> <td>H</td> </tr> </table>			Electrical Interface Options			Input	Output		+ 5V dc nom.± 0.5V	0.5 to 4.5V dc ratiometric	A	24V dc nom. +9-28V	0.5-4.5V dc	G	±15V dc nom. ±9-28V	±5V dc	B	24V dc nom. +13-28V	0.5 to 9.5V dc	C	± 15V dc nom. ±13-28V	±10 V dc	D	24V dc nom. +18-28V	4 to 20mA (2 wire)	E	24V dc nom. +13-28V	4 to 20mA (3 wire sink)	F	24V dc nom. +13-28V	4 to 20mA (3 wire source)	H						
Electrical Interface Options																																						
Input	Output																																					
+ 5V dc nom.± 0.5V	0.5 to 4.5V dc ratiometric	A																																				
24V dc nom. +9-28V	0.5-4.5V dc	G																																				
±15V dc nom. ±9-28V	±5V dc	B																																				
24V dc nom. +13-28V	0.5 to 9.5V dc	C																																				
± 15V dc nom. ±13-28V	±10 V dc	D																																				
24V dc nom. +18-28V	4 to 20mA (2 wire)	E																																				
24V dc nom. +13-28V	4 to 20mA (3 wire sink)	F																																				
24V dc nom. +13-28V	4 to 20mA (3 wire source)	H																																				
<table border="1"> <tr> <th colspan="2">Calibration Adjusters</th> </tr> <tr> <td>Trim Pots Accessible</td> <td>Blank</td> </tr> <tr> <td>Sealed Trim Pots</td> <td>Y</td> </tr> </table>			Calibration Adjusters		Trim Pots Accessible	Blank	Sealed Trim Pots	Y																														
Calibration Adjusters																																						
Trim Pots Accessible	Blank																																					
Sealed Trim Pots	Y																																					
<table border="1"> <tr> <th colspan="3">Connector / Cable</th> </tr> <tr> <td>Connector - Axial IP65</td> <td>Hirschmann GD series</td> <td>J</td> </tr> <tr> <td>Cable - Axial Gland IP67</td> <td>Please specify cable length in cm.</td> <td>Lxx eg. L2000 specifies 20 metres of cable with an axial cable gland</td> </tr> <tr> <td>Cable - Axial Short Gland IP67</td> <td>Please specify cable length in cm.</td> <td>Mxx Note: restricted cable pull strength</td> </tr> </table>			Connector / Cable			Connector - Axial IP65	Hirschmann GD series	J	Cable - Axial Gland IP67	Please specify cable length in cm.	Lxx eg. L2000 specifies 20 metres of cable with an axial cable gland	Cable - Axial Short Gland IP67	Please specify cable length in cm.	Mxx Note: restricted cable pull strength																								
Connector / Cable																																						
Connector - Axial IP65	Hirschmann GD series	J																																				
Cable - Axial Gland IP67	Please specify cable length in cm.	Lxx eg. L2000 specifies 20 metres of cable with an axial cable gland																																				
Cable - Axial Short Gland IP67	Please specify cable length in cm.	Mxx Note: restricted cable pull strength																																				
<table border="1"> <tr> <th colspan="3">OPTIONS</th> </tr> <tr> <th colspan="3">Spring Return</th> </tr> <tr> <td>Fitted</td> <td></td> <td>N</td> </tr> <tr> <th colspan="3">Housing</th> </tr> <tr> <td>Flanged</td> <td>Standard option no code</td> <td>Blank</td> </tr> <tr> <td>Servo Mount</td> <td></td> <td>P</td> </tr> </table>			OPTIONS			Spring Return			Fitted		N	Housing			Flanged	Standard option no code	Blank	Servo Mount		P	Option 1				Option 2													
OPTIONS																																						
Spring Return																																						
Fitted		N																																				
Housing																																						
Flanged	Standard option no code	Blank																																				
Servo Mount		P																																				

For more information, please contact:  
 Everight Precision Technologies Corporation  
 102 Commerce Dr., Unit 8, Moorestown, NJ 08057  
 www.everightsensors.com info@everightsensors.com  
 phone: 856-727-9500 fax: 610-672-9663